


CODE WARRIOR JR.™ ADJUSTMENTS



CONTACT - SPACING: Spacing between the lever arm contacts and the contact post set screws is realized by adjusting the contact set screw to increase or decrease the distance. (1)

PADDLE TENSION: Each paddle may be separately adjusted for optimum tension. Paddle arm screw (3) being closer to the magnet increases tension. Moving the paddle arm screw away from the magnet decreases the tension. To adjust the tension, you must remove the lever. Using the allen wrench supplied either tighten or loosen to your feel. If the paddle arm screw is placed too far away from the magnet, the key will lose its positive feel. The set screw (2) placed in the center block can be adjusted to hold the paddle tension screw away from the magnet according to your feel. To adjust the set screw in center block, remove from base and use allen wrench supplied. Usually the CW operator will not find it necessary to change the initial adjustment.